

# Lynx L500REF - Instruction on Changing the Kickplate


2023/11/30

J&L Industries Inc.

- 1) Prepare a cross-slotted (Phillips) screwdriver thin enough to be inserted into the kickplate slots.



- 2) Unscrew the screws at four corners



- 3) Replace it with a new kickplate and screw it on securely.